NOTES TO USERS

This map is for use in administering the National Flood Insurance Program. It does not necessarily identify all areas subject to flooding, particularly from local drainage sources of small size. The community map repository should be consulted for possible updated or additional flood hazard information.

processer upwares of Abbitterin Isoto Indel Distribution.
To obtain more detailed information in aces where Base Flood Elevations (in E.) and/or floodwarp have been determined, users are encouraged to control detailed information in the second second second second second tables contained within the Flood Insures Study (FIS) general half accomparise files information in the second second second second second second particular second second second second second second second information. Accordingly load sevaled data presented in the FIS reput should helphanism. Accordingly load sevaled data presented in the FIS reput should helphanism. Accordingly load sevaled data presented in the FIS reput should helphanism.

Costal Base Flood Elevations shown on his map apply only landward of 0.0° North American Vertical Datum of 1988 (VAVD 88). Users of this FIRM should be avare that costal hood devalitors are also provided in he Sammay of Sillware Elevations table in the Flood Insurance Study Report for this jurisdiction. Iterators shown in the Sammary of Sillware Iterations table should be used for construction, and/or floodpain management purposes when they are higher than the devalutions shown in the FIRM.

Boundaries of the **floodways** were computed at cross sections and interpolate between cross sections. The floodways were based on hydraulic consideration with regard to requirements of the National Flood Insurance Program. Floodwa widths and other pertinent floodway data are provided in the Flood Insurano Study report for this jurisdiction.

Certain areas not in Special Flood Hazard Areas may be protected by flood control structures. Refer to Section 2.4 'Flood Protection Measures' of the Flood Insurance Study report for information on flood control structures in this jurisdiction.

The projection used in the preparation of his map was New Mexico State Plane West Zone (#PS 3003). The horizontal datum was NADB3, GRSB0 spheroid production of FIRMs for adjacent jurisdicions may result in sight positional differences in map features across jurisdiction boundaries. These differences do not affect the accuracy of his FIRM.

Flood severities on this map are referenced to the North American Vertical Datum of 1989. These flood development be compared to structure and ground relevations referenced to the same vertical datum. For information regarding conversion between the National Geodetic Vertical Datum of 1929 and the North American Vertical Datum of 1980, with the National Geodetic Survey eablies at http://www.ngs.noas.gov or contact the National Geodetic Survey ablies the North address:

NGS Information Services NOAA, N/NGS12 National Geodetic Survey, SSMC-3, #9202 1315 East-West Highway Silver Spring, Maryland 20910-3282 (301) 713-3242

To obtain current elevation, description, and/or location information for **bench** marks shown on this map, please contact the information Services Branch of the National Geodetic Survey at (301) 713-3242, or visit their website at http://www.ngs.noaa.gov/.

Base map information shown on this FIRM was derived from multiple sources. This information was compiled from the United States Geological Savey, 1999, the National Geodetic Survey, 2007, the Forderal Emergency Management Agency, 1988 and 2002, US. Bareau of Land Management 2006, U.S. Census Bareau, 2000 and 2003 and San Juan County, 2007. Additional information was photogrametically compiled at a scale of 11/2000 tom New Mexico Resource Geographic Information System setial photography data 2004.

This map relects more detailed and up-to-date stream channel configurations than those shown on the previous FRM for this jurisdicion. The floodpairs and floodnays that were transferred from the previous FRM may have been adjusted to conform to these new steam channel configurations. As a result, the Flood Profiles and Floodpair Data bables in the Flood Instances David report (which confisms abs/floodpairs) bable steam the Prod Instances David report (which confisms abs/floodpairs) bable steam in the Prod Instances David report (which confisms abs/floodpairs) bable steam in the Prod Instances of the Prod Instances of Borne nith may and abs/floodpairs).

Corporate limits shown on this map are based on the best data available at the time of publication. Because changes due to annexations or de-annexations may have occurred after this map was published, map users should contact appropriate community diricials to verify current corporate limit locations.

Please refer to the separately printed **Map Index** for an overview map of the county showing the layout of map panels; community map repository addresses; and a Listing of Communities table containing National Fload Insurance Porgram dates for each community as well as a listing of the panels on which each community is located.

Contact the FEMA Map Service Center at 1-800-358-9616 for information on available products associated with this FIRM. Available products may include perviculy issued Letters of Map Change, a Flood Insurance Study report, and/or digital versions of this map. The FEMA Map Service Center may also be reached by Fax at 1-800-559-602 and ther website at Http://www.msc.lema.gov.

If you have questions about this map or questions concerning the National Flood Insurance Program in general, please call 1- 877- FEMA MAP (1-877-336-2627) or visit the FEMA website at http://www.fema.gov/.

